




USB Port

**Important! Intuit QuickBooks Point of Sale software must be installed before connecting your hardware. To install hardware for Point of Sale, you will need your Point of Sale installation CD. If you don't have your installation CD, drivers are available at <http://support.quickbooks.intuit.com>**

**You will need one available USB port to connect and use this device.**



Representative images only;  
actual product may vary.

### Hardware Setup and Installation

1. Make sure the Point of Sale installation disc is in your CD-ROM drive.  
(Cancel the Installation Wizard if it launches.)
2. Launch Point of Sale. Select **Hardware Setup Wizard** from the **File** menu.
3. Follow the onscreen instructions to connect and set up your PIN Pad.  
**Do not connect the PIN pad to your PC until prompted to do so.**